

SIOUX CITY ORPHEUM LINE SET

ITEM		DISTANCE FROM PROS. WALL
A	LAMBREQUIN	-2'-6"
B	FIRE CURTAIN	0'-2 1/2"
1	VALANCE GUIDE WIRED (4-LINE)	1'-0"
2	MAIN CURTAIN	1'-6"
3	SCENERY BATTEN	2'-0"
4	No. 1 HOUSE ELECTRIC	2'-6"
5	SCENERY BATTEN	3'-0"
6	SCENERY BATTEN	3'-6"
7	SCENERY BATTEN	4'-0"
8	No. 1 HOUSE LEG TRACKED (TRACK NR)	4'-6"
9	PICTURE SCREEN (NR)	5'-0"
10	SCENERY BATTEN	5'-6"
11	SCENERY BATTEN	6'-0"
12	ACOUSTICAL SHELL (NR)	6'-6"
13	No. 1 HOUSE BORDER	7'-6"
14	No. 2 HOUSE LEG TRACKED (TRACK NR)	8'-0"
15	No. 2 HOUSE ELECTRIC	8'-6"
16	SCENERY BATTEN	9'-6"
17	SCENERY BATTEN	10'-0"
18	SCENERY BATTEN	10'-6"
19	SCENERY BATTEN	11'-0"
20	No. 2 HOUSE BORDER	11'-6"
21	MID STAGE TRAVELER (TRACK NR)	12'-0"
22	SCENERY BATTEN	12'-6"
23	SCENERY BATTEN	13'-0"
24	SCENERY BATTEN	13'-6"
25	No. 3 HOUSE BORDER	14'-0"
26	No. 3 HOUSE LEG TRACKED (TRACK NR)	14'-6"
27	No. 3 HOUSE ELECTRIC	15'-0"
28	SCENERY BATTEN	15'-6"
29	ACOUSTICAL SHELL (NR)	16'-0"
30	SCENERY BATTEN	17'-0"
31	SCENERY BATTEN	17'-6"
32	SCENERY BATTEN	18'-0"
33	SCENERY BATTEN	18'-6"
34	No. 4 HOUSE BORDER	19'-0"
35	No. 4 HOUSE LEG TRACKED (TRACK NR)	19'-6"
36	SCENERY BATTEN	20'-0"
37	SCENERY BATTEN	20'-6"
38	SCENERY BATTEN	21'-0"
39	No. 4 HOUSE ELECTRIC	21'-6"
40	No. 5 HOUSE BORDER	22'-6"
41	REAR TRAVELER	23'-0"
42	SCENERY BATTEN	23'-6"
43	SCENERY BATTEN	24'-0"
44	SCENERY BATTEN	24'-6"
45	ACOUSTICAL SHELL (NR)	25'-0"
46	SCENERY BATTEN 4-LINE SYSTEM	27'-0"
47	SCENERY BATTEN 4-LINE SYSTEM	29'-0"

NR, DENOTES NON-REMOVABLE ITEMS
40' PIPE LENGTH - 6" CENTERS TYPICAL

APRIL, 2003